

# STAKE POCKET MOUNT - (SPM)

## USER INSTRUCTIONS:

### To attach stake pocket mount to truck:

- Take off side shims until Stake pocket mount fits into stake pocket
- Loosen the four bolts
- Insert stake pocket mount into stake pocket on truck
- Spread the four bolts outward until stake pocket is wedged securely
- Tighten middle bolt until secured firmly
- Tighten outside four bolts

### To remove Stake Pocket Mount:

- Loosen four outer bolts first
- Loosen middle bolt second
- Remove Mount from Stake Pocket

[www.DriverIndustrial.com](http://www.DriverIndustrial.com)



Manufactured By:

**SafetyWhips® USA**

*2115 W. Mountain View RD., Phoenix, AZ 85021*

*Ph: 602-424-2500 Fax: 602-424-9777*

*Email: Sales@DriverIndustrial.com*

***In Canada***

*2677 192nd St. #107, Surrey, BC V3Z 3X1 Canada*

*Ph: 604-560-5080 Fax: 604-560-5090*

*Email: SalesCanada@SafetyWhips.com*

[www.DriverIndustrial.com](http://www.DriverIndustrial.com)