




SafetyWhips® Warning Whip Bases & Adapters

Powered & Non-Powered options available!

Whip Mount Bases


Threaded Whip Receiving Mounts



Steel Thread Mounts

- a : 519.343NP Non-powered
b : 519.343-RCA RCA Type power connector w/ RCA type pigtail
c : 519.343 wire in pigtail

Quick Disconnect Receiving Mounts



Stainless Steel QD Mount Use with quick disconnect whips

- d : SWQDNP: Non-powered
e : SWQD-PT: wire in pigtail
f : SWQD-R: RCA Type power connector w/ RCA type pigtail



Heavy Duty Spring Mount Highly recommended to help reduce whip breakage.

Shown with:
ABM: Angle Bracket Mount

Powered:

- g : 519.309 Stainless Steel
h : 519.30B Zinc Plated Steel



Non-powered:

- i : 519.309NP Stainless Steel
j : 519.30BNP Zinc Plated Steel



Whip Mount Threaded To Quick Disconnect Adapters

For use converting 1/2 inch 20 thread whip connection to QD
Available as Adapter Only or in Kit with Receiving QD Mount

Non-powered

k

l



k : SWQD-KIT-NP,
(kit)

l : SWQD-WA-NP
(adapter only)

Powered w/ lead

m

n



m : SWQD-KIT-PT
(kit)

n : SWQD-WA
(adapter only)

Powered w/ detachable RCA lead

o

p



o : SWQD-KIT-R
(kit),

p : SWQD-WA
(adapter only)